



Installation Template

1. Cut along dotted line
2. Moisten and paste onto wall
3. Drill holes
(Circles indicate screw position)

