

# INSTALLATION INSTRUCTIONS

## 安裝說明

1. Check the size of gap (g) between Hand Shower and Hose with existed Gasket.

先檢查花灑與蛇管間隙值  $g$ 。

2. Insert Extra Gasket into bell nut of Hose as  $g < 1.0\text{mm}$ ; if  $g > 1.0\text{mm}$ , you could skip this step.

若  $g < 1.0\text{mm}$ ，將所附墊片再放入蛇管喇叭頭內；若  $g > 1.0\text{mm}$  則可跳過此步驟，不用放墊片。

3. Cover Protector on bell nut of Hose, and then tightly assemble Hand Shower and Hose.

將保護套包在喇叭頭，然後鎖緊花灑與蛇管。

4. Remove the C Fixed Ring from Bracket and position the Hand Shower on.

將掛架內的C型塑膠拆掉，並將花灑插入掛架。

